

---

## 1 Contents

2	System Requirements .....	10
2.1	Hardware:.....	10
2.2	Software:.....	10
2.3	Screen Resolution: .....	10
3	Recommended Reading .....	11
4	Quick Start Guide .....	12
4.1	Charge the PSY1 Internal Battery.....	12
4.2	Clean the Psychrometer Chamber .....	12
4.3	Install the PSY1 Software & USB Driver .....	12
4.4	Turn the Instrument On .....	12
4.5	Connect to the Instrument .....	12
4.6	Set the Measurement Protocols .....	13
4.7	Calibrate the Sensor.....	13
4.8	Install the Sensor.....	13
4.9	Set the Logging Interval .....	13
4.10	Download Data .....	13
4.11	Analyse Data .....	13
5	Description.....	14
5.1	Stem Psychrometer Chamber .....	14
5.2	Calibration:.....	15
5.3	Clamping: .....	15
5.4	Measurement Options:.....	15
5.5	Measurement of Stem Water Potential: .....	15
5.6	Measurement of Leaf Water Potential:.....	16
5.7	Measurement of Osmotic Potential: .....	16
5.8	PSY1 Stem Psychrometer Meter:.....	16
5.8.1	Water Proofing:.....	17
5.8.2	Power Management: .....	17
5.8.3	External power:.....	17
5.8.4	Tools:.....	17
5.8.5	Power Fail Safe Mode: .....	17
5.8.6	Lightning Protection:.....	18

---

5.8.7	Data Storage & Memory: .....	18
5.8.8	Communication:.....	18
5.8.9	Software & Firmware:.....	18
5.8.10	Operating Temperature Range: .....	18
6	Theory .....	19
6.1	Stem Water Potential.....	19
6.1.1	Turgor pressure.....	19
6.1.2	Osmotic potential.....	19
6.1.3	Matric Potential .....	19
6.1.4	Gravity.....	19
6.2	Psychrometric measurement.....	20
6.3	Psychrometric measurement protocol .....	22
6.4	Psychrometric equation:.....	23
6.4.1	Psychrometric Wet Bulb Depression .....	23
6.4.2	Chamber Temperature.....	24
6.4.3	Delta-T ( $\Delta T$ ) .....	24
6.5	Psychrometric error .....	25
6.6	Equilibration Time.....	25
6.7	Zero Offsets:.....	26
6.8	Temperature Gradient .....	26
6.9	Condensation: .....	27
6.10	Osmotic Potential.....	28
6.10.1	Collecting an Extracted Sap Sample.....	28
7	Charging – Powering the instrument.....	30
7.1	PSY1 Current draw .....	31
7.2	Connecting a Power Supply to the Instrument.....	32
7.3	Connecting Power Directly via Solar Panel .....	33
7.4	Connecting Power via External 12V Battery .....	34
7.5	Connecting Power via External 12V Battery and Solar Panel .....	35
7.6	Sharing an External 12V Battery and Solar Panel via Daisy Chaining .....	36
7.7	Connecting Power via AC Mains 12V DC Plug Pack .....	37
8	Handling the Instrument.....	38
9	Adjusting Thermocouples .....	38
10	Cleaning the Psychrometer.....	40

---

---

10.1	Cleaning routine.....	41
10.1.1	Cleaning the psychrometer using Chloroform.....	42
10.1.2	Cleaning the psychrometer using Electronic Contact Cleaner.....	43
10.2	Diagnosing a Dirty Thermocouple.....	45
10.3	Storing the Stem Psychrometers .....	49
11	Software & USB Driver Installation .....	51
11.1	Instrument Set-up and Configuration .....	51
11.2	PSY1 Utility Software .....	51
11.2.1	Installation: .....	51
12	Turn the Instrument on.....	53
12.1	Turn the PSY1 ON.....	53
12.2	Turning the PSY1 OFF.....	54
13	Communications – Connect to the Instrument .....	55
13.1.1	The opening Splash Screen displays the following: .....	55
13.1.2	A status bar along the bottom of the window.....	55
13.1.3	<i>Connect to PSY</i> .....	55
13.2	USB Connection: .....	56
13.2.1	USB Connection Type.....	56
13.2.2	USB Find Devices.....	56
13.2.3	USB Select Device.....	57
13.3	MCC1 - RF Modem: .....	59
13.3.1	RF Connection Type .....	59
13.3.2	RF Find Devices .....	59
13.3.3	RF Select Device .....	59
13.3.4	RF Device Chooser.....	60
13.3.5	RF Discover.....	60
13.3.6	RF Device Wake Up Routine .....	61
13.3.7	RF Search for more Devices .....	61
13.3.8	Saving discovered devices as a group.....	62
14	LED's.....	64
14.1	Power Circuit LED's .....	64
14.1.1	LED Flash Sequence Definitions .....	64
14.2	USB Communication LED's.....	64
14.2.1	Red LED .....	64

---

---

14.2.2	Green LED.....	64
14.3	Device Firmware .....	65
14.4	Power down:.....	65
15	Measurement Protocols .....	66
15.1	Calibration Settings.....	66
15.2	Measurement Options.....	67
15.2.1	Cooling Time: .....	67
15.2.2	Wait Time:.....	71
15.3	Reverse Peltier (Warming).....	71
15.4	Chamber Heating .....	71
16	Calibration.....	74
16.1	Pre-Calibration Cleaning .....	74
16.2	Calibration Temperature.....	75
16.3	Calibration Chamber .....	75
16.4	Calibration Protocol .....	76
16.4.1	Start Calibration .....	76
16.4.2	Loading the Calibration Filter Paper .....	77
16.4.3	Selecting the Calibration Range .....	77
16.4.4	Start Measurement.....	78
16.4.5	Generate Calibration Curve .....	78
16.4.6	Write Calibration to Firmware .....	79
16.4.7	Calibration storage location.....	80
16.4.8	Loading a Different Calibration .....	80
16.4.9	Default Calibration .....	81
16.5	Checking for calibration drift .....	82
16.6	Manual Editing of the Calibration .....	83
16.6.1	Edit the Calibration .....	84
16.6.2	Save Current Calibration to HDD .....	85
16.6.3	Load saved Calibration from HDD.....	86
16.6.4	Calibration Live View Mode .....	87
16.6.5	Calibration Summary file (*.rdf).....	88
16.6.6	Calibration File .....	88
16.6.7	Calibration History File.....	89
17	Installation .....	90

---

---

17.1	In-situ Measurements of Stem Water Potential.....	90
17.2	Selecting a Sample .....	91
17.3	Sample Preparation .....	93
17.3.1	Sample Preparation on Woody Stems .....	93
17.3.2	Identifying the xylem .....	96
17.3.3	Sample Preparation on Herbaceous Stems .....	99
17.4	Positioning Thermocouple-S.....	100
17.5	Instrument Attachment .....	101
17.6	Sealing the Exposed Site .....	102
17.7	Insulation .....	103
17.8	De-Installation & Re-Installation.....	104
17.9	Installation on Large Diameter Stems.....	105
17.9.1	Modified Surface Attachment.....	105
17.9.2	Forstner Bit Installation.....	107
18	Instrument Setup & Configuration .....	112
18.1	Instrument Information .....	112
18.1.1	Name:.....	112
18.1.2	Comment: .....	112
18.1.3	PSY Serial No: .....	113
18.1.4	The X: .....	113
18.1.5	Update Instrument Information: .....	113
18.1.6	SD Card:.....	113
18.1.7	SD Card Initialisation:.....	113
18.1.8	SD Card Formatting:.....	114
18.1.9	Instructions to reformat a MicroSD Card.....	114
18.1.10	Format Check: .....	114
18.1.11	File Name Error: .....	114
18.1.12	Serial Number: .....	115
18.1.13	Icon:.....	115
18.1.14	APP Serial #: .....	115
18.1.15	COM Serial #:.....	115
18.1.16	O:.....	116
18.1.17	APP Ver.: .....	116
18.1.18	COM Ver.:.....	116

---

---

18.1.19	External Supply: .....	116
18.1.20	Battery:.....	117
18.1.21	Status: .....	117
18.2	Raw Data Tab .....	117
18.2.1	dT: .....	119
18.2.2	Chamber Temp:.....	119
18.2.3	Wet Bulb: .....	119
18.2.4	Measurement Status:.....	119
18.2.5	Show Diagnostics .....	120
18.3	Measurement Statistics .....	122
19	Measurement Control.....	123
19.1	Measurement Mode .....	123
19.1.1	Manual: .....	123
19.1.2	10 Min: .....	124
19.1.3	15 Min: .....	124
19.1.4	20 Min: .....	124
19.1.5	30 Min: .....	124
19.1.6	60 Min: .....	124
19.2	Live Mode:.....	125
19.2.1	Live Logging Interval.....	126
19.2.2	Live Data file.....	128
19.3	Delayed Start.....	129
19.4	Dialogue Box .....	131
19.4.1	C: .....	132
19.4.2	X: .....	132
19.5	Status Bar: .....	132
19.5.1	Connection status: .....	132
19.5.2	Batt:.....	133
19.5.3	Port:.....	133
19.5.4	Device Date: .....	133
19.5.5	Device Time:.....	133
19.5.6	Help Menu: .....	133
19.5.7	Check for Updates.....	134
19.5.8	Support.....	134

---

---

20	Peltier Cooling Curve.....	135
20.1.1	Get Latest Data: .....	135
20.1.2	Plot: .....	135
20.2	Peltier Cooling Curve Plot .....	136
20.3	Peltier Cooling Curve – Diagnostic Tool .....	137
20.3.1	Plot Options: .....	138
20.3.2	Copy: .....	138
20.3.3	Save Image As.....	138
20.3.4	Page Setup .....	139
20.3.5	Print.....	139
20.3.6	Show Point Values.....	140
20.3.7	Zoom .....	141
20.3.8	Un-Zoom .....	141
20.3.9	Undo all Zoom/Pan .....	141
20.3.10	Set to Default Scale .....	141
20.4	Peltier Cooling Curve Raw Data File.....	143
21	Data Storage & Downloading.....	145
21.1.1	Main Data File .....	145
21.1.2	Raw Measurement Data .....	145
21.1.3	Live Data.....	145
21.2	SD Card Logging Options.....	145
21.3	Downloading Data.....	146
21.3.1	Via USB Cable .....	147
21.4	Via MicroSD card USB Adapter .....	147
21.5	Windows FAT-32 compatible.....	148
21.6	Micro SD Card Memory Capacity.....	148
21.7	Renaming data files.....	148
21.8	Data File Format.....	148
22	Appendices.....	149
22.1	PSY1 Test Procedure .....	149
22.2	Electronic Contact Cleaners .....	151
22.3	Compressed Air.....	151
22.4	Preparation of Calibration Solutions.....	152
22.5	Osmotic Coefficients and Water Potentials of Sodium Chloride Solutions .....	153

---

---

22.6	Copper/Constantan Thermocouple Conversion Chart .....	153
22.7	Correction Factors – Ambient Temperature Relationship (MPa/°C) .....	154
22.8	PSY1 Installation Kit .....	155
22.9	Support Log .....	159
22.10	Debug File .....	160
22.11	Extension Cable Specs .....	161
22.12	SD Card Re-Initialisation.....	161
23	Contact Details.....	162